HANGZHOU JUNPU OPTOELECTRONIC EQUIPMENT CO.,LTD

Installation Manual

1. Description:

The equipment is used as a termination point for the feeder cable to connect with drop cable in FTTx communication network system. The fiber splicing, splitting, distribution can be done in this box, and meanwhile it provides solid protection and management for the FTTx network building.

2. Features:

- 1, Total enclosed structure.
- 2. Material: PC+ABS, wet-proof, water-proof, dust-proof, anti-aging, protection level up to IP66.
- 3. Clamping for feeder cable and drop cable, fiber splicing, fixation, storage, distribution...etc all in one.
- 4. Cable, pigtails, patch cords are running through own path without disturbing each other, cassette type SC adaptor installation, easy maintenance.
- 5. Distribution panel can be flipped up, feeder cable can be placed in a cup-joint way, easy for maintenance and installation.
- 6. Cabinet can be installed by the way of wall-mounted or poled-mounted, suitable for both indoor and outdoor uses.

3. Specification:

1, Environmental requirement

Working temperature: $-40^{\circ}\text{C} \sim +85^{\circ}\text{C}$ Relative humidity: $\leq 85\%$ (+30°C) Atmospheric pressure: $70\text{KPa} \sim 106\text{Kpa}$

2. Main technical datasheet

Insertion loss: ≤0.2dB UPC return loss: ≥50dB APC return loss: ≥60dB

Life of insertion and extraction: >1000 times

3. Thunder-proof technical datasheet

The grounding device is isolated with the cabinet, isolation resistance is less than $2\times10^4 \text{M}\,\Omega/500\text{V}$ (DC);

 $IR \ge 2 \times 10^4 M \Omega / 500 V$

The withstand voltage between grounding device and cabinet is no less than 3000V (DC) /min, no puncture, no flashover; $U \ge 3000V$


4. Configuration table:

Table 1 Model and configuration


Model	Descripti	Size (Pic 1)	Max Capacity			Installation Size(Pic 2)	Cable
	on	A*B*C (mm)	SC	LC	PLC	D*E (mm)	ways
FAT-24B	Fiber Access Terminal	340*250*110	24	48	1 x 1:16/ 3 x 1:8	145*120	Cutted/unc utted cable

Email: sales@junpu-catv.com Skype ID: alicema62 WhatsApp: 86-18868807126

HANGZHOU JUNPU OPTOELECTRONIC EQUIPMENT CO.,LTD








Pic 2 Installation Size

5. Product cable ways:



1. Lid; 2. Lock coat; 3. Lock; 4. Seal gasket; 5. Splicing flap plate; 6. Adaptor holder; 7. Adaptor; 8. Lid lock joint bracket; 9. Lid lock clip; 10. Base; 11. Cable strengthen mound layer; 12. Cable entrance; 13. Lock panel; 14. PLC mounting position

Pic 4 Cable ways


6. Installation:

1. Wall-mounted installation


Drill 4 holes over the wall based on the size in table 1, place the expansion bolt Φ 7.5*40, place the box to match up the holes and use bolt to fasten. (Pic 4)

2. Pole-mounted installation

Fix 1 set of the easy pole ring to the telecom pole. (Pic 5)



Pic 5 Wall mounted installation



Pic 5 Pole ring installation

Email: sales@junpu-catv.com Skype ID: alicema62 WhatsApp: 86-18868807126

HANGZHOU JUNPU OPTOELECTRONIC EQUIPMENT CO.,LTD

Email: sales@junpu-catv.com Skype ID: alicema62 WhatsApp: 86-18868807126